CLEANING

**USE ON ALL KEURIG®* K-CUP®* BREWERS**

caffenu®

*Cleaner Machine*
***Better Coffee***

**RECOMMENDED USAGE:** Use one cleaning pod weekly (recommended), or after making flavored beverages/tea. Use at least once a month or after every 30 cups. **NOT A DESCALER!** Please also remember to descale your brewer with our Caffenu® Eco Descaler every 2-4 months.

***Estimated Duration: 5 - 10mins**

## CLEANING GUIDELINES FOR KEURIG®* K-CUP®*

(OPEN & TURN FOR DESCALING INSTRUCTIONS)

## CLEANING IN 4 EASY STEPS

**1. INSERT**
Insert pod like you would a coffee pod. Close machine.

**2. BREW**
Brew cleaning pod. Wait 1 minute.

**3. EJECT**
Eject and dispose of the cleaning pod. Close machine.

**4. RINSE**
Brew twice on an 8 oz setting to rinse.

## ENGLISH

**AFTER CLEANING:** Clean the appliance. Wipe inside of pod holder. CAUTION! Brew needle.

### USAGE INSTRUCTIONS FOR KEURIG®* BREWERS *(EXCEPT MINI RANGES)*

**Ensure water reservoir is full; place large container under brew spout.**

Insert pod, close handle, and press small or Cocoa/other brew button. Wait 1 minute.
Remove used pod (CAUTION: Hot!). Don't drink solution!
Rinse with large brew button.
Open and close brewer. Press large brew button to rinse again.
Discard solution or use to soak drip tray for 10 minutes, then rinse.

TIP: Periodically clean water entry and exit needle with a thin, sharp object (e.g. a paper clip) for best results after using a cleaning pod and before rinsing.

### USAGE INSTRUCTIONS FOR KEURIG®* MINI BREWERS

**Power on brewer; place large mug under brew spout.**

Fill the water reservoir with 6 fl oz of water.**
Insert the cleaning pod into the pod holder.
Lower the handle and press the brew button, waiting for the cycle to finish.
Remove the used pod (CAUTION: Hot!). Don't drink solution!
For rinsing, fill the water reservoir to max (10 fl oz).
Ensure pod holder is empty, lower the handle, and press the brew button to rinse, waiting for the cycle to finish.
Repeat the rinse (steps 5–6).
Discard solution or use to soak drip tray for 10 minutes, then rinse.

****Some Mini brewers may require you to lift and lower handle first to fill water compartment.**

## FRENCH

**APRÈS LE NETTOYAGE : Nettoyez l'appareil. Essuyez l'intérieur du compartiment où se place la capsule. FAITES ATTENTION AUX POINTES ASSERÉES D'INFUSION !**

### MODE D'EMPLOI POUR TOUTES LES MACHINES À INFUSER *(SAUF LES FORMATS MINI)*

**Assurez-vous que le réservoir d'eau est plein ; placez un grand récipient sous le bec d'infusion.**

Soulevez la poignée. Insérez la capsule dans son compartiment, puis abaissez la poignée. Appuyez sur le plus petit bouton d'infusion ou utilisez le bouton CACAO/AUTRE pour infuser.
Attendez 1 minute.
Soulevez la poignée et retirez la dosette de nettoyage. ATTENTION ! CHAUD ! Ne buvez pas la solution de nettoyage !
Abaissez la poignée ; appuyez sur le grand bouton d'infusion ou sur l'infusion d'eau pour rincer.
Ouvrez et abaissez la poignée ; appuyez sur le grand bouton d'infusion ou sur l'infusion d'eau pour rincer à nouveau.
Jetez la solution ou, mieux encore, utilisez la solution pour faire tremper le bac récepteur pendant 10 minutes, puis rincez.

CONSEIL : De temps en temps, il est recommandé de nettoyer les pointes d'entrée et de sortie d'eau à l'aide d'un objet fin et pointu (par exemple, un trombone ou un objet similaire). Le nettoyage est plus efficace après l'utilisation de la capsule de nettoyage et avant le rinçage.

### INSTRUCTIONS D'UTILISATION POUR LES FORMATS MINI

**Mettez la machine en marche ; placez une grande tasse sous le bec d'infusion.**

Remplir 6 fl oz dans le compartiment à eau. **
Soulevez la poignée. Insérez la dosette de nettoyage dans le porte-dosette.
Abaissez la poignée. Appuyez sur le bouton d'infusion et attendez que le cycle se termine.
Soulevez la poignée et retirez la capsule de nettoyage. ATTENTION ! CHAUD ! Ne buvez pas la solution de nettoyage !
Pour rincer, abaissez la poignée et remplissez le compartiment à eau jusqu'au maximum, soit 10 fl oz.
Soulevez la poignée ; assurez-vous que le compartiment à capsule est vide. Abaissez la poignée. Appuyez sur le bouton de d'infusion pour rincer et attendez que le cycle se termine.
Répétez la procédure de rinçage des étapes 5 et 6.
Jetez la solution ou, mieux encore, utilisez la solution pour faire tremper le bac d'égouttage pendant 10 minutes, puis rincez.

****Pour certaines mini-cafetières, il faut d'abord soulever puis abaisser la poignée pour remplir le compartiment à eau.**